

Contactless Card Read/Write Module

YW-201-C

User's Manual

(version 1.4)

English

WEB:	http://www.yoworfid.com
MSN&EMAIL:	coodor@126.com
PHONE:	086-10-59395668
MOBILE:	086-13671114914
MANAGER:	Mr Zhou

Content

1	Summary	3
2	YW-200-C Series Module	3
3	YW-201-C Characteristic	3
4	Function specification	4
4.1	Pin Function	4
4.2	Dimension	5
5	Protocols.....	5
5.1	UART Protocols of Commands.....	5
5.2	IIC Protocol.....	7
5.3	Switch of Uart and IIC	8
6	Command List.....	8
7	Command test sample	12
7. 1.	request card	13
7. 2.	read block	13
7. 3.	write block	13
7. 4.	download key	13
7. 5.	initial purse	13
7. 6.	read purse	13
7. 7.	increment of purse	13
7. 8.	decrement of purse	13
7. 9.	purse backup	13
7. 9. 1	initial purse 1	13
7. 9. 2	initial purse 2	13
7. 9. 3	purse backup from 1 to 2	13
7. 9. 4	read purse 2	14
7. 10.	card halt	14
7. 11.	read RC500EEPROM	14
7. 12.	write RC500EEPROM	14
7. 13.	module IDLE	14
7. 14.	module set	14
8	Order	14

1 Summary

YW-201-C contactless card Read/Write module was designed on high integrated reader ICs for contactless communication on 13.56MHz of Philips. YW-201 integrates MF RC500 RF base station . Engineers need not take care how to control MF RC500 RF base station. Just send command to module over IIC or UART.

YW-200 series contactless card Read/Write module support ISO14443-A Mifare One S50, S70, UltraLight, MifarePro, ISO14443-B SR176, ISO15693 , I CODE SL2 and then other compatible card.

2 YW-200-C Series Module

Type	Card Protocol	Vcc	Interface	Card supported	This Page
YW-201-C	ISO14443-A	+5V	IIC,UART(TTL)	Mifare S50,S70, Mifare Pro	✓
YW-202-C	ISO14443-A ISO14443-B	+3.3V~+5V	IIC,UART(TTL)	Mifare S50,S70, Mifare Pro, ISO14443-B SR176	
YW-203-C	ISO15693	+3.3V~+5V	IIC,UART(TTL)	ICode SL2, ISO15693	
YW-204-C	ISO14443-A ISO14443-B ISO15693	+3.3V~+5V	IIC,UART(TTL)	Mifare S50,S70, Mifare Pro, ISO14443-B SR176, ICode SL2, ISO15693	

3 YW-201-C Characteristic

» Completely operation of Mifare One through simple command set.

☞ Communication Protocol:

1. UART: Baud Rate 19200bps.
2. IIC: Max rate 400Kbps.

☞ Auto request card: When the card put into antenna, the pin “CARDIN” will be low.


☞ Power supply :+4.5~+5.5V.

☞ Read Card distance 5~10cm. (Depend on the antenna)

☞ You can get C51 source code example with the module.

4 Function specification

4.1 Pin Function



Pic 1


Pin function [Table 1] :

Pin	Function	Description
1	VCC	+5V VCC
2	GND	GND
3	RXD/SCL	UART RXD/ IIC SCL
4	TXD/SDA	UART TXD/ IIC SDA
5	CARDIN	Card In/Out Indicate(Only when auto request) 0:Card In. 1:Card Out.
6	PORTSEL	Communication Protocol Selector (0: IIC, 1: UART)
7	NC	Not Use
8	NC	Not Use

9	NC	Not Use
10	NC	Not Use

Table 1

4.2 Dimension



Pic 2

5 Protocols

5.1 UART Protocols of Commands

Uart Protocols of Commands use data blocks. The format of data block :

1) Format of TXD (MCU → YW-201-C Module)

	[STX]	[LEN]	[CMD]	[DATA]	[CHK]	[ETX]
Description	0x02	Package Length	Commad	The Content of n bytes	CheckSum	0x03
Number of Byte	1	1	1	n	1	1

Table 2

- a) Asynchronism half duplex, 1 Start bit + 7 Data bits + 1 Stop bit.
- b) The default transfer speed is 19200 bit/s.

- c) Block Header STX=0x02, Block End ETX=0x03. From header to end , but not include the header STX and the end ETX, if there is 0x02, 0x03 or 0x10 , then must add 0x10 before it.
- d) Block Header STX=0x02.
- e) Package Length: the byte from Length itself to Checksum, but not include the added byte 0x10 due to 0x02, 0x03 or 0x10.
- f) Command: Refer to the Command List.
- g) The Content of n bytes: the parameter.
- h) CheckSum: XOR result from [**Length**] to then last byte of [**Content**], but not include the added byte 0x10 due to 0x02, 0x03 or 0x10.
- i) Block End ETX=0x02.

Example:

CMD: 0x10, DATA:0x00

Block Header:0x02.

LEN:0x04 (=1Byte (Len) +1Byte (CMD)+1Byte (DATA)+1Byte (CHK))

CMD:0x10, 0x10. (Add 0x01 before 0x10)

DATA:0x00.

CHECKSUM:0x14 (=0x04 ^ 0x10 ^ 0x00)

Package Send:0x02, 0x04, 0x10, 0x10, 0x00, 0x14, 0x03.

2) Respond Format (**YW-201-C** module → MCU)

	[STX]	[LEN]	[CMD]	[STATUS]	[DATA]	[CHK]	[ETX]
Content	0x02	Package Length	Command	0x00: Success 0xFF: Fail	The Content of n bytes	CheckSum	0x03
Num of Byte	1	1	1	1	n	1	1

Table 3

- a) Asynchronism half duplex, 1 Start bit + 7 Data bits + 1 Stop bit.
- b) The default transfer speed is 19200 bit/s.

- c) Block Header STX=0x02, Block End ETX=0x03. From header to end , but not include the header STX and the end ETX, if there is 0x02, 0x03 or 0x10 , then must add 0x10 before it.
- d) Block Header STX=0x02.
- e) Package Length: the byte from Length itself to Checksum, but not include the added byte 0x10 due to 0x02, 0x03 or 0x10.
- f) Command: Refer to the Command List. When the MCU send the command to the module, the module send back this command to the MCU.
- g) Status: Operation result. Success: 0x00. Fail: 0xFF.
- h) During the communication, command content.
- i) CheckSum: XOR result from [**Length**] to then last byte of [**Content**], but not include the added byte 0x10 due to 0x02, 0x03 or 0x10.
- j) Block End ETX=0x02.

5.2 IIC Protocol

1) Format of TXD(MCU → YW-201-C Module)

	[Address of module] (W/R)	[LEN]	[CMD]	[DATA]	[CHK]
Content	Write: 0xA0	Package Length	Command	The Content of n bytes	CheckSum
	Read: 0xA1				
Num of Byte	1	1	1	n	1

Table 4

- a) Address of module (W/R):
- b) When Write to module, the Address is 0xA0.
- c) When Read from module, the Address is 0xA1.
- d) Package Length: the byte from Length itself to Checksum.
- e) Command: Refer to the Command List.
- f) The Content of n bytes: the parameter.

- g) CheckSum: XOR result from [**Length**] to then last byte of [**DATA**].

2) Respond Format(**YW-201-C** module → MCU)

	[LEN]	[CMD]	[STATUS]	[DATA]	[CHK]
Content	Package Length	Command	0x00:Success 0xFF: Fail	The Content of n bytes	CheckSum
Num of Byte	1	1	1	n	1

Table 5

- h) Package Length: the byte from Length itself to Checksum.
 i) Command: Refer to the Command List.
 j) Status: Operation result. Success: 0x00. Fail: 0xFF.
 k) The Content of n bytes: the parameter.
 l) CheckSum: XOR result from [**Length**] to then last byte of [**DATA**].

5.3 Switch of Uart and IIC

YW-201-C Contactless card read/write module support UART and IIC, they can be switched by the port PORTSEL

PORSEL = 1(High), UART is selected.

PORSEL = 0(Low), IIC is selected.

6 Command List

	[CMD Name]	[Dir]	[LEN]	[CMD]	[STATUS and DATA]	[Description]
System Command						
1	Module Setting	Send	0x04	0x01	0x00	4 combination with bit0 and bit1: Antenna Status (BIT0)
					0x01	0: Turn off Antenna
					0x02	1: Turn on Antenna

Contactless Card Read/Write Module (**YW-201-C**) User's Manual

					0x03	Auto Request (BIT1) 0: Turn off Auto Request 1: Turn on Auto Request
2	Power Setting	Return	0x04	0x01	0x00	Status: 0x00: Success 0xFF: Fail
					0xFF	
3	Request Card	Send	0x03	0x02		
		Return	0x04	0x02	0x00	Status: 0x00: Success 0xFF: Fail
Contactless card Command						
4	Read Block	Send	0x04	0x10	0x00	Request card mode: 0x00: request all card in antenna area 0x01: request card that have not halted in antenna area
					0x01	
5	Write Block	Return	0x08	0x10	0x00	Status: 0x00: Request success + Card Serial No(4 bytes). 0xFF: Request Fail.
			0x04		0xFF	
		Send	0x0B	0x11	8Byte	Key Set (1Byte) + Block No (1Byte) + Key (6Bytes) a. Key Set (1Byte): Select Key A, B (BIT0) -> 0: Key A; 1: Key B Key Mode (BIT1) -> 0: Use key passed. 1: Use key downloaded. b. Index of Key Downloaded (BIT2 ~ BIT7) -> 0 ~ 31
		Return	0x14	0x11	0x00	0x00: Success, 16 bytes of data return.
			0x04		0xFF	0xFF: Fail
						Key set (1Byte) + Block No (1Byte) + Key (6Bytes) + Data (16Bytes) a. Key Set (1Byte): Select Key A, B (BIT0) -> 0: Key A; 1: Key B

Key Mode (BIT1) ->

Contactless Card Read/Write Module (**YW-201-C**) User's Manual

						->0~31
		Retur n	0x04	0x12	0x00 0xFF	Status: 0x00: Success 0xFF: Fail
6	Read Sector	Send	0x0B	0x13	8bytes	Key Set(1Byte) + Index of Sector(1Byte) +Key(6Bytes) a. Key Set(1Byte): Select Key A, B(BIT0)->0:Key A;1:Key B Key Mode(BIT1)-> 0:Use key passed. 1:Use key downloaded. b. Index of Key Downloaded(BIT2~BIT7) ->0~31
						0x00: success, 64bytes of data return.
		Retur n	0x44	0x13	0x00 0xFF	Dat a 0xFF: Fail
7	Initialize purse	Send	0x0F	0x14	12Bytes	Key Set(1Byte) + Index of Block(1Byte) + Key(6Bytes) +Purse Initial Value (4Bytes, LSB) a. Key Set(1Byte): Select Key A, B(BIT0)->0:Key A;1:Key B Key Mode(BIT1)-> 0:Use key passed. 1:Use key downloaded. b. Index of Key Downloaded(BIT2~BIT7) ->0~31
						0x00: Success 0xFF: Fail
		Retur n	0x04	0x14	0x00 0xFF	Status: 0x00: Success 0xFF: Fail
8	Read purse	Send	0x0B	0x15	8Bytes	Key Set(1Byte) + Index of Block(1Byte) + Key(6Bytes) a. Key Set(1Byte): Select Key A, B(BIT0)->0:Key A;1:Key B Key Mode(BIT1)-> 0:Use key passed. 1:Use key downloaded. b. Index of Key Downloaded(BIT2~BIT7) ->0~31
						0x00: Success, 4bytes of purse value(LSB)
		Retur n	0x08 0x04	0x15	0x00 0xFF	Dat a 0xFF: Fail

Contactless Card Read/Write Module (**YW-201-C**) User's Manual

9	decrement	Send	0x0F	0x16	12Bytes	<p>Key Set(1Byte) + Index of Block(1Byte) + Key(6Bytes) + value of decrement(4Bytes, LSB)</p> <p>a. Key Set(1Byte): Select Key A, B(BIT0) -> 0:Key A; 1:Key B Key Mode(BIT1)-></p> <p> 0: Use key passed. 1: Use key downloaded.</p> <p>b. Index of Key Downloaded(BIT2~BIT7) -> 0~31</p>
		Return	0x04	0x16	0x00 0xFF	<p>Status:</p> <p>0x00: Success 0xFF: Fail</p>
10	Increment	Send	0x0F	0x17	12Bytes	<p>Key Set(1Byte) + Index of Block(1Byte) + Key(6Bytes) + value of Increment(4Bytes, LSB)</p> <p>a. Key Set(1Byte): Select Key A, B(BIT0) -> 0:Key A; 1:Key B Key Mode(BIT1)-></p> <p> 0: Use key passed. 1: Use key downloaded.</p> <p>b. Index of Key Downloaded(BIT2~BIT7) -> 0~31</p>
		Return	0x04	0x17	0x00 0xFF	<p>Status:</p> <p>0x00: Success 0xFF: Fail</p>
11	Purse backup	Send	0x0C	0x18	9Bytes	<p>Key Set(1Byte) + Index of Block(1Byte) + Index of Block Backup(1Byte) + Key(6Byte)</p> <p>a. Key Set(1Byte): Select Key A, B(BIT0) -> 0:Key A; 1:Key B Key Mode(BIT1)-></p> <p> 0: Use key passed. 1: Use key downloaded.</p> <p>b. Index of Key Downloaded(BIT2~BIT7) -> 0~31</p> <p>ps: the index of block and the backup block must be in the same sector.</p>
		Return	0x0C	0x18	0x00 0xFF	<p>Status:</p> <p>0x00: Success 0xFF: Fail</p>
12	Card Halt	Send	0x03	0x19	/	

		Retur n	0x04	0x19	0x00 0xFF	Status: 0x00: Success 0xFF: Fail	
13	Key Download	Send	0x0A	0x1A	Index of key (1Byte , 0~31) + Key (6Bytes)		
		Retur n	0x04	0x1A	0x00 0xFF	Status: 0x00: Success 0xFF: Fail	
14	Read RC500 EEPROM	Send	0x06	0x1B		Address(2Bytes)+Length(1Bytes) Ps: Address: High byte afront Length: not more than 16	
		Retur n	n+4	0x1B	0x00	Dat a	0x00: success, n(Length) bytes of data return.
			0x04		0xFF		0xFF: fail
15	Write RC500 EEPROM	Send	n+5	0x1C	N bytes data	Address(2Bytes)+Data(nBytes) Ps: Address: High byte afront Data: not more than 16 bytes.	
		Retur n	0x04	0x1C	0x00 0xFF	0x00: Success 0xFF: Fail	

Table 6



Turn on the antenna before the operation of contactless card.

7 Command test sample

Samples below are based on uart protocol.

7.1. request card

Send: 02 04 10 10 00 14 03

Receive: 02 08 10 10 00 4D 56 A2 57 F6 03

7.2. read block

Send: 02 0B 11 00 3E FF FF FF FF FF 24 03

Receive: 02 14 11 00 00 01 00 00 00 00 00 00 00 00 00 00 00 04 03

7.3. write block

Send: 02 1B 12 00 3E FF FF FF FF FF 00 01 00 00 00 00 00 00 00 00 00 00 00 00 00 36 03

Receive: 02 04 12 00 16 03

7.4. download key

Send: 02 0A 1A 00 FF FF FF FF FF 10 10 03

Receive: 02 0A 1A 00 FF FF FF FF FF 10 10 03

7.5. initial purse

Send: 02 0F 14 00 3D FF FF FF FF FF 01 00 00 00 27 03

Receive: 02 04 14 00 10 10 03

7.6. read purse

Send: 02 0B 15 00 3D FF FF FF FF FF 23 03

Receive: 02 08 15 00 10 02 00 00 00 1F 03

7.7. increment of purse

Send: 02 0F 16 00 3D FF FF FF FF FF 01 00 00 00 25 03

Receive: 02 04 16 00 12 03

7.8. decrement of purse

Send: 02 0F 17 00 3D FF FF FF FF FF 01 00 00 00 24 03

Receive: 02 04 17 00 13 03

7.9. purse backup

7.9.1 initial purse 1

Send: 02 0F 14 00 3D FF FF FF FF FF 01 00 00 00 27 03

Receive: 02 04 14 00 10 10 03

7.9.2 initial purse 2

Send: 02 0F 14 00 3C FF FF FF FF FF 05 00 00 00 22 03

Receive: 02 04 14 00 10 10 03

7.9.3 purse backup from 1 to 2

Send: 02 0C 18 00 3D 3C FF FF FF FF FF 15 03

Receive: 02 04 18 00 1C 03

7. 9. 4 read purse 2

Send: 02 0B 15 00 3C FF FF FF FF FF FF 22 03

Receive: 02 08 15 00 FF 04 00 00 E6 03

7. 10. card halt

Send: 02 10 03 19 1A 03

Receive: 02 04 19 00 1D 03

7. 11. read RC500EEPROM

Send: 02 06 1B 00 70 10 10 7D 03

Receive: 02 14 1B 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 0F 03

7. 12. write RC500EEPROM

Send: 02 15 1C 00 70 FF 79 03

Receive: 02 04 1C 00 18 03

7. 13. module IDLE

Send: 02 10 03 10 02 01 03

Receive: 02 04 10 02 00 06 03

7. 14. module set

Send: 02 04 01 00 05 03(turn off antenna)

Receive: 02 04 01 00 05 03

Send: 02 04 01 01 04 03(turn on antenna)

Receive: 02 04 01 00 05 03

8 Order

Web:<http://www.yoworfid.com>

Phone:+86-10-59395668

Cell phone:+86-13671114914

Email:coodor@126.com